


CN1
CONTROLS INPUT



NOTE:
SOLDER JUMPERS JP4, JP5, JP6 ARE NOT CONNECTED BY DEFAULT

